

To change the amount of time before delayed ringing.

From any phone with a display:

Press Feature

Dial # 0 * 8 9 7 4 on the keypad

Press Line key 1


Press Line Key 2

Dial 2 6 on the keypad


Enter the amount of time you would like before a call begins to delay ring it can be from 00-99 seconds

Press Transfer

Press Speaker to exit programming.



DTP-16D-1



These are the line keys, Line Key 1 is in the upper left corner as shown