

DND indication on DSS Console.

This is a common request when a user upgrades (or downgrades as some would say) to an IVS/IVS2/IPS from a Key System. By default the NEC key system displays the DND status of a station on a DSS console. With the IVS/IVS2/IPS this is obtainable with the following programming.

1. First you must assign the Console to the system using CM's 10, 96, and 97.
2. Using CM 97 assign a DND Set-Reset key to key 57 E.g. 97>00,57>F1053.
3. Now when a station is placed in DND the LED to the top right of the DSS key will light green.
4. If key 57 is depressed (LED top left of key red) any station selected on the DSS will be placed into DND or removed depending on the status.
5. To stop this from being pressed (Fat finger dialing) you can remove the 2 screws from the back of the unit after confirming the key is in the off position and unit unplugged. Inside another 6 screws removed enables you to pull out the PC board. On the key side you will see a rubber mat covering the buttons and LED's. Lift the rubber mat and place a small piece of cellophane tape over the white lines under the button marked L58. **Note 1.**
6. Carefully re-assemble the DSS unit.
Now pressing this DND key will have no effect and the DSS feature will stay in place.

Note 1: Performing step 5 and 6 will void NEC warranty on the DSS console device. Perform this step at your own discretion as it is NOT necessary.